

HEAD GASKET	DESCRIPTION-FEL-PRO #
HG-1AC-80	HEAD GASKET-8724PT
HG-1MZFE-94L	HEAD GASKET-9201PT
HG-1MZFE-94R	HEAD GASKET-9203PT
HG-1UZFE-90L	HEAD GASKET-9805PT
HG-1UZFE-90R	HEAD GASKET-9806PT
HG-20R-75	HEAD GASKET-21187PT
HG-21R-80	HEAD GASKET-21R
HG-22R-81	HEAD GASKET-8807PT1
HG-2JZGE-93	HEAD GASKET-SUPRA
HG-2RZFE-95	HEAD GASKET-9831PT
HG-2SELC-83	HEAD GASKET-9148PT
HG-2TZFE-90	HEAD GASKET-9831PT
HG-2VZFE-89L	HEAD GASKET-9656PT
HG-2VZFE-89R	HEAD GASKET-9657PT
HG-3AC-83	HEAD GASKET-9082PT
HG-3E-87	HEAD GASKET-9483PT
HG-3SFE-87	HEAD GASKET-9480PT
HG-3SGELC-86	HEAD GASKET-3SGELC 86
HG-3VZE-88L	HEAD GASKET-99815PT
HG-3VZE-88R	HEAD GASKET-9728PT
HG-3VZFE-92L	HEAD GASKET-9904PT
HG-3VZFE-92R	HEAD GASKET-9905PT
HG-3YEC-84	HEAD GASKET-9230B
HG-420A-95	HEAD GASKET-
HG-4AC-83	HEAD GASKET-9410PT
HG-4AC-86	HEAD GASKET-9410PT
HG-4AF-88	HEAD GASKET-8188 PT 4AF
HG-4AFE-93	HEAD GASKET-9604PT
HG-4AGE-85	*HEAD GASKET-9383PT
HG-4G15-91	HEAD GASKET-9758PT
HG-4G37-89	HEAD GASKET-9846B
HG-4G63-89	*HEAD GASKET-9086PT

HG-4G64-93	HEAD GASKET-9932PT
HG-4XE1-90	HEAD GASKET-9684PT
HG-4YEC-86	HEAD GASKET-9417 PT 4YEC
HG-4ZD1-86	HEAD GASKET-9496PT
HG-4ZE1-88	HEAD GASKET-8215PT
HG-5EFE-92	HEAD GASKET 9963PT
HG-5EFE-95	HEAD GASKET-TERCEL
HG-5ME-81	HEAD GASKET-8834PT
HG-5MGE-82	HEAD GASKET-8969PT
HG-5SFE-90	HEAD GASKET-9861/9480PT
HG-5VZFE-95L	HEAD GASKET,L- 9227 PT
HG-5VZFE-95R	HEAD GASKET,R- 9227 PT
HG-6G72-88	HEAD GASKET-6G72
HG-6G72D-91	HEAD GASKET-6G72D
HG-6G74-94	HEAD GASKET-MITSUBISHI
HG-7AFE-93	HEAD GASKET-9955 PT
HG-7MGE-86	HEADGASKET-9473PT
HG-A20A-87	HEAD GASKET-9429PT
HG-B17A1-92	HEAD GASKET-9274PT
HG-B18A1-90M	HEAD GASKET-9698PT
HG-B20A3-88	HEAD GASKET-9124PT-1
HG-B20B4-97	HEAD GASKET-CRV
HG-B6-86	HEAD GASKET-9461PT
HG-B6-90	HEAD GASKET-9696B
HG-B6E-90	HEAD GASKET-9691PT
HG-BPD-90M	HEAD GASKET-9717PT-1
HG-BPS-90M	HEAD GASKET-9718PT
HG-C25A1-86	HEAD GASKET-9450PT
HG-C27A1-87	HEAD GASKET-9531PT
HG-C27A4-95	HEAD SET- 9531PT
HG-C32A1-91	HEAD GASKET-9031PT
HG-CA18-84	*HEAD GASKET-9236PT
HG-CA20-82	HEAD GASKET-9236PT
HG-D15B1-88	HEAD GASKET-9123PT

HG-D15Z1-92	HEAD GASKET-9123PT-2
HG-D16A1-86	HEAD GASKET-9451PT-1
HG-D16Y5-96	HEAD GASKET-9915PT/9123
HG-D16Z6-92	HEAD GASKET-9915 PT
HG-E15-82	HEAD GASKET-8973PT
HG-E16-84	HEAD GASKET-9376PT
HG-EK1-79	HEAD GASKET-8736PT
HG-EK1-82	HEAD GASKET-8970PT
HG-EM1-80	HEAD GASKET-21214PT-1
HG-ES1-83	*HEAD GASKET-9233 PT
HG-ES3-85	*HEAD GASKET-HONDA
HG-ET2-86	HEAD GASKET-9440PT
HG-EV1-84	HEAD GASKET-9219PT-1
HG-F2-88	HEAD GASKET-9572PT
HG-F22A1-90M	HEAD GASKET-9851 PT
HG-F22B2-94M	HEAD GASKET-9958 PT
HG-F23A1-98	HEAD GASKET-ACCORD 2.3
HG-F23A1-98M	HEAD GASKET
HG-FE-83	HEAD GASKET-9139B
HG-FS-93	HEAD GASKET-9711PT
HG-G13A-86	HEAD GASKET 9117PT-1
HG-G15B-85	HEAD GASKET-9352PT
HG-G16KC-89	HEAD GASKET-9683PT
HG-G180Z-76	HEAD GASKET-8621PT-1
HG-G200Z-83	HEAD GASKET-8621PT-1
HG-G54B-83	HEAD GASKET-8770PT-1
HG-G6-89	HEAD GASKET-9637PT
HG-G62B-83	HEAD GASKET-9149PT
HG-G63B-83	*HEAD GASKET-9086PT
HG-G64B-85	HEAD GASKET-9338PT
HG-G64B-93	HEAD GASKET 9338PT
HG-GA16DE-91	HEAD GASKET-9819 PT
HG-GA16i-89	HEAD GASKET-9645PT
HG-H22A1-93	HEAD GASKET-PRELUDE

HG-H23A1-92	HEAD GASKET-9919PT
HG-JE39-88LM	HEAD GASKET-9649PT
HG-JE39-88RM	HEAD GASKET-9650PT
HG-KA24DE-91	HEAD GASKET-9820PT
HG-KA24DE-93	HEAD GASKET-9942 PT
HG-KA24E-89	HEAD GASKET-9646PT
HG-L28E-75	HEAD GASKET-21157PT-1
HG-L28E-81	HEAD GASKET-8799PT
HG-MA-79	HEAD GASKET-8502PT
HG-QR25DE-02	NISSAN ALTIMA 02-04 2.5L
HG-SR20DE-91	HEAD GASKET-9816PT
HG-VG30-84	HEAD GASKET-9571PT
HG-VG30DE-90	HEAD GASKET-9703PT
HG-VG30E-93	HEAD GASKET 9972PT QUEST 93-98
HG-VQ30DE-95L	HEAD GASKET-9508PT MAXIMA
HG-VQ30DE-95R	HEAD GASKET-9508PT MAXIMA
HG-Z20-80	HEAD GASKET-NISSAN
HG-Z22-81	HEAD GASKET-NISSAN
HG-Z24-83	HEAD GASKET-9210PT-1